




WATER FILTER

The British Berkefeld water filter shares many characteristics with the Rolls Royce automobile. Both are old marques, both are made in Great Britain, and each, in its respective field, represents the pinnacle of quality. The British Berkefeld SS-4 uses ceramic "Super SterasyI" filters to reduce up to 99.99% of particulates, cysts, parasites and pathogenic bacteria including but not limited to E. Coli, Cryptosporidium, Giardia and Salmonella Typhi. These filters will reduce chlorine, rust, sediment and organic chemicals with nominal particulate filtration rating efficiencies of 99.99% filtration at 0.9 microns, 99.9% at 0.5 microns, and 98% at 0.2 microns.

The durable ceramic filters can be cleaned many times with a soft brush or Scotch Brite pad. Each element will filter up to 2000 gallons, depending on water turbidity. Filtration rate is 1 gallon per hour and works by gravity, so electricity is not required. Easy to follow assembly and operating instructions are included. Housing is gleaming stainless steel. For durable, proven, foolproof delivery of pure water, British Berkefeld is the answer.



Connections	Water is poured manually into the upper chamber
Filter Candle Grade (see colour code)	SterasyI™, Super SterasyI™ or ATC Super SterasyI™ 
Filter Candle Type	7 inches (178mm) long with long threaded mount & wing nut
Number of filter candles	2, 3 or 4 filter candles depending on flow rate required
Output	Approximately 20 litres per candle per 24 hour period

Le fabricant et nous même, nous réservons le droit de modifier le produit en vue d'une amélioration